

BRAKE TYPE DESIGNATION REFERENCE

Brake type designation letters appear at the end of new or reman shoe & kit part numbers to indicate the make and type of brake.

Brake Type Designation	Brake Manufacturer	Brake Type
B	Bendix	Bendix (core)
B	Bendix	Cam Brake (reman shoes)
BW	Bendix	Wedge Brake
D	Dexter	12-1/4" PQ Brake
D	Dana/Spicer	16-1/2" XL Brake
E	Eaton	Standard Eaton Brake / ES II Reman Kits (where there is no ES I)
E1	Eaton	ES Brake - 1st Version
E2	Eaton	ES Brake - 2nd Version
EC	Eaton	Cast Shoe (reman shoes)
EH	Eaton	High Mount Shoe
ES	Eaton	ES II (where there is no ES I) (reman shoes)
F2	Fruehauf	XEM - 2nd Version
F3	Fruehauf	XEM - 3rd Version
F3L	Fruehauf	8-5/8" LH Offset XEM3 Shoe
F3R	Fruehauf	8-5/8" RH Offset XEM3 Shoe
F5	Fruehauf	XEM Retrofit (core)
FC2	Dana/Spicer	Fast Change II Brake
G2	Eaton	ES II (core)
H	Eaton	High Mount (core)
H	Meritor	Q Brake with HeavyDuty Webs (core)
L	Meritor	Lucas Hydraulic (reman shoes)
M	Meritor	Q Brake with Heavy Duty Webs (Mack) (reman kits)
MF	Meritor	Fruehauf XEM Retrofit
P	Meritor	P Brake
PC	Meritor	Cast P Brake
Q	Meritor	Q Brake
QA	Meritor	Q Brake for 1.68" Offset Spider with Relocated Retainer Spring Hole
QM	Meritor	Q Brake with Heavy Duty Webs (Mack)
QP	Meritor	Q Plus Brake
QPM	Meritor	Q Plus Brake with Heavy Duty Webs (Mack)
QPR	Meritor	Q Plus Brake with High Mount Spring Hole
QR	Meritor	Q Brake with Relocated Return Spring Hole (Mack)
R	Meritor	Stopmaster Wedge Brake (core)
RC	Meritor	18" Cast Shoe (reman shoes)
RD	Meritor	Stopmaster Wedge Brake (new shoes)
S	Standard Forge	Standard Forge Brake
SM	Meritor	Stopmaster Wedge Brake (reman shoes)
T	Meritor	T Brake
U	Dana/Spicer	U Brake
W	Wagner	Wagner Air or Hydraulic Brake Shoe
W5, W6, W8	Wagner	Wagner 1308 Air Brake Front Shoes